

Sectional Door Framing Instructions 09 422 2299 Roller Industrial - Series B/C

- Work area to be clear prior to installation (width of door and 3 meters back)
- No other persons in the work area during installation
- Inside face on sides and above door to be flush
- Wall and ceiling to be lined prior to installation and all paint/plaster to be completely dry

Warning: Delays or non installation due failure to adhere to these instructions may incur additional charges.

Note: Side fixing for the motor or chain is dependent on which side of the door it is on. The sides are indicated as left (L) or right (R) looking from the inside of the garage outwards.

All measurements are in millimetres. **Minimum Clearances:** Headroom (up to 3300h) 500 CONTINUE STUDS Backspace (up to 3300h) 570 Headroom (3300-5000h) 600 Backspace (3300-5000h) 670 Motor Side: Side Fixing no motor/chain 135 3 stud / 135mm full height Extra fixing from opening up Side Fixing Chain 225 (L) / 240 (R) Side Fixing GDO10 250 (L) / 270 (R) Side Fixing GDO12 190 (L) / 210 (R) REBATE WOTH = OPENING WOTH + 200M Windlock Add 50 to above Non motor/chain side: 3 stud / 135mm full height side fixing Rebate 100mm past opening 100mm back from architrave

Note: Headroom is measured from the underside of the trim to the lowest point. This includes any GIB cove or beams that are lower than the ceiling.

Note: For Automatic operation a power point is required on the wall within 1.0m of the unit.

Site Specific:

25mm deep

Lintel:	Architraves:
Side fixing:	Trim:
Ceiling:	Rebate:
Gib Cove:	